

Free flow, High strength, Non Shrink, Cementitious precision grout

Uses

Conbextra BB92-IN is designed for precision grouting of Foundations subjected to static & Dynamic loads. Its specifically suitable for grouting base frame of metal wind turbine foundations and also horizontal & vertical joints of precast wind turbine towers

Advantages

- High early & Ultimate compressive strength
- Excellent flow characteristics and rheology permits pumping
- Dynamic Load resistant
- Non Shrink
- Prepacked material overcomes onsite batching variations

Description

Conbextra BB92-IN is supplied as ready to use dry powder which is blend of Portland Cement, graded fillersand chemical additives which impart a controlled expansion in plastic state, while minimising water demand.

Technical support

An experienced technical advisory team is available to give technical service on request.

Technical Properties

Test method	Typical result
Mixed Density	: 2.4 kg/litre
Expansion	: 0-1%
Mixing ratio w/p	: 2.75 - 3.0 Ltrs/25 kg
Thickness applicable	: 10-300 mm
Final Set	: < 5 hours
Compressive strength (ASTM C 109 50.00mm cubes)	: > 30 N/mm ² @ 1 day : > 75 N/mm ² @ 7 days : > 90 N/mm ² @ 28 days
Flexural Strength (BS 4551, 40x40x160mm)	: > 4 N/mm ² @ 1 day : > 10 N/mm ² @ 7 days : > 12 N/mm ² @ 28 days
Initial flow (BS 890 Cone)	: 240-280 mm

The above results corresponds to a W/P ratio of 0.11.

The following results were obtained at 27°C

Application instructions

Surface Preparation

The substrate surface must be free from oil, grease or any loosely adherent material. If the concrete surface is defective or has laitence, it must be cut back to a sound base. Bolt holes and fixing pockets must be blown clean of any dirt or debris.

Pre Soaking

Several hours prior to placing, the concrete substrates should be saturated with fresh water.

Immediately before grouting takes place any free water should be removed with particular care being taken to blow out all bolt holes and pockets.

Base Plate

It is essential that this is clean and free from oil, grease or scale. Air pressure relief holes should be provided to allow venting of any isolated high spots.

Levelling Plates

If these are to be removed after the grout has hardened, they should be treated with a thin layer of grease.

Formwork

The formwork should be constructed leak-proof given the high fluidity of grout. This can be achieved by using foam rubber strip or mastic sealant beneath the constructed formwork and between joints.

In some cases it is practical to use sacrificial semi dry sand and cement formwork the formwork should include outlets for presoaking.

Un restrained surface area should be kept to a minimum, Generally the width of the gap between the perimeter of the casing and the plate should not exceed 150mm at the discharge side and 50mm on the opposite side. There should be no holes in the sides.

Mixing

For best results use a mechanical powered grout mixer should be used. When quantities upto 50Kg are used, slow speed drill (400-500Rpm) fitted with a paddle is suitable, large quantities will require a heavy duty mixer. Place the water into the mixer and add the contents of the Conbextra BB92-IN bag Mix for 5minutes to ensure uniform consistency.

Note: during the first two or three minutes, the mixture will have a hard consistency. Add 2.75 to 3.0 Liters of water to a 25kg bag to obtain a fluid grout.

Fosroc® Conbextra BB92-IN



Placement

In order to maximize the expanding effect is convenient to place the grout within 15minutes of mixing, Conbextra BB92-IN can be placed upto thickness of 300mm. The Bolts should be fixed with mortar or resin before pouring.

It is essential that the discharge/pumping is continuous. Always make sure to have enough grout before starting and controlling the time of mixing and the time needed to prepare the next batch.

The discharge must always be performed from the same side of the bed to prevent the formation of air pockets. Efforts will be made to the advancing front of the grout is uniform.

In case of pumping, prior lubrication of all equipment by a cementitious slurry composed of two parts of cement and water in sufficient quantity for the circuit to be in contact with the grout be lubricated. Grout should be pumped after lubrication, eliminating the initial slurry used for lubrication.

Curing

To complete the operation, air exposed areas should be cured. This should be done by Concure curing membrane, continuous application of water and/or wet hessian.

Cleaning

All tools and equipment can be cleaned simply with water immediately after use, if the material is hardened clean mechanically or with a solution of Fosroc Acid etch

Packing

Conbextra BB92-IN : 25 kg and
500 kg jumbo bag

Storage

Conbextra BB92-IN has a shelf life of 6 months kept in a dry store in sealed bags. If stored in high temperature and high humidity locations the shelf life may be reduced.

Precautions

Health and Safety

Conbextra BB92-IN is alkaline and should not come in contact with skin and eyes. Avoid inhalation of dust during mixing. Use Gloves, goggles and mask.

If there is contact with skin, wash with water, Splashes in the eyes should be washed immediately with clean water and consult a Doctor. Do not induce vomiting.

Fire

Conbextra BB92-IN is not flammable.

For additional information, please refer to product SDS.



FRANKLIN FLOOR TECH
OFFICE ADDRESS ADDRESS:
HOUSE# 553, SHAHINBAG, TEJGAON, DHAKA 1215, BANGLADESH.
PHONE: 01715-289292 E-MAIL:CHASHIMASUM@GMAIL.COM,
WEBSITE : WWW.FRANKLIN.COM.BD